



## AD10-2 HAND HELD METAL DETECTOR USER GUIDE

**OPERATION:** Press white on/off pushbutton and sweep for detection of metal making sure the pushbutton is kept depressed whilst sweeping. The detection of metal is indicated by means of a digital audio and visual signal. For general personnel searching, hold detector further away for large items such as weapons. For smaller items sweep detector closer to target area.

**BATTERY:** Any 9V battery such as PP3, 6F22 or equivalent will operate satisfactorily. In common with all our AD series of hand held metal detectors, the AD10-2 will give greatly extended life on a single battery, up to 1 year with daily use. First indication that the battery will need to be replaced is a prolonged alarm signal leading eventually to a continuous alarm. The battery is contained inside the hatch cover located on the underside and accessed by 1 screw. The battery may be removed by compressing the battery against the tension spring and withdrawing the battery. Replacing battery: Insert battery against tension spring which should then be compressed, insert battery into compartment taking care to ensure + and - polarities are correct.

**2 YEAR WARRANTY:** Our range of metal detectors are manufactured to the most stringent standards of quality, every care is taken to ensure our products give efficient and reliable service. In the unlikely event of failure due to defective parts, return unit to direct to our factory or approved service centre whereupon an immediate service will be carried out.

All the above are plus carriage which must be paid forward. The above warranty does not affect the consumer's statutory rights.

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

ADAMS ELECTRONICS  
1611 SOUTH UTICA AVE., PMB #: 408, TULSA, OKLAHOMA 74104 USA  
Tel: 918-622-5000 Fax: 918-622-5005  
E-Mail: [adamselectronics@hotmail.com](mailto:adamselectronics@hotmail.com) Website: [www.adamsinc.com](http://www.adamsinc.com)

