



AD11-V HAND HELD METAL DETECTOR USER GUIDE

OPERATION: Press WHITE On/Off pushbutton switch and sweep for detection of metal making sure the pushbutton is kept depressed whilst sweeping. The detection of metal is indicated by means of a digital audio signal and visual L.E.D. To the left of the WHITE Push-button is a YELLOW rocker function switch. This two position switch controls the alarm indication. In the forward position alarm indication is vibration only. This vibration indication allows discrete detection. With the YELLOW function switch in the back position the alarm indication is audio and visual simultaneous.

BATTERY: Any 9V battery such as PP3, 6F22 or equivalent will operate satisfactorily. The Battery Low Indicator YELLOW LED illuminating signals the need to replace the battery. The battery is contained inside the hatch cover located on the underside and accessed by 1 screw. The battery may be removed by compressing the battery against the tension spring and withdrawing the battery. Replacing battery: Insert battery against tension spring which should then be compressed, insert battery into compartment taking care to ensure + and - polarities are correct.

2 YEAR WARRANTY: Our range of metal detectors are manufactured to the most stringent standards of quality. Every care is taken to ensure our products give efficient and reliable service. In the unlikely event of failure due to defective parts, return the unit to your supplier or direct to our factory whereupon an immediate service will be carried out.

All the above are plus carriage which must be paid forward. The above warranty does not affect the consumer's statutory rights

ADAMS ELECTRONICS
1611 SOUTH UTICA AVE., PMB #: 408, TULSA, OKLAHOMA 74104 USA
Tel: 918-622-5000 Fax: 918-622-5005
E-Mail: adamselectronics@hotmail.com Website: www.adamsinc.com

